




LUNA 3

Quick Start Guide


Accessories



LUNA 3





Power Adapter



Stylus or Digitizer

Overview



Charging & Power On


First Time Use

LUNA 3 is under “Battery Ship Mode” and will not power on to preserve the battery and prevent power loss. To enable “Regular Mode” and activate the battery, please connect the power adapter to power on.




1. Please fill the battery and then discharge it completely once before use to recalibrate the capacity.
2. Please always use AC adapter included in the package. If user wants to use other Type C PD adapter, please make sure that adapter can provide more power than 65 watts.

1. LUNA 3 supports 2 USB Type C connections and either one can be used for power
2. Connect the AC adapter to the DC-IN port. If charge by side port, please open the compartment cover first before connecting.




3. After charging, disconnect the AC adapter. If charge by side port, please close the compartment cover and seal after disconnection.
4. After fully charged, press and hold the power button until the screen lights. The device runs through the startup sequence and powers up.



Installing the Pen Holder

1. Install pen holder with screws to the LUNA 3.



Installing the Micro SIM Card (Optional)

LUNA 3 includes two Micro SIM card slot for cellular and wireless connection. Only a Micro SIM card is supported in the slot.

1. Power off LUNA 3.
2. Open the lower right I/O compartment cover.
3. Take the Micro SIM card from its packaging. The Micro SIM card has a corner missing. Align the SIM card with the slot making sure that the corners match.
4. Insert the Micro SIM card and press it in until an audible click sounds and close the I/O compartment cover.

